SPECIFCATION SHEET



NITROGEN OXIDES ANALYZER

Model GLN-314E

This instrument provides continuous and reliable measurement of Nitrogen Oxides in ambient air. Measurement is based on the principle of chemiluminescence as specified in ISO-7996 (Ambient air - Determination of the mass concentration of nitrogen oxides - Chemiluminescence method).

The instrument is designed for long term, continuous measurement, logging and data output.

Features

Compliance with all relevent standards

US-EPA tested and approved and in full compliance with EN measurement standards.

User friendly operation

Large backlit display shows plain English data and menus. No complex commands or error codes to memorize.

Touch screen panel

User control and data input is by means of the touch screen panel. The various menus are accessed by touching the appropriate menu choice on the screen. Alphanumeric data is input using the on-screen key pad.

Flexible data output formats

Both analogue and digital format outputs are available for connection to external data loggers and telemetry systems.

Powerful data aquisition functions

The instrument has its own integrated data logger system. Diagnostic information is recorded alongside the measurement data and historical data can be displayed on the screen in the form of tables or graphs. Data can also be transferred to optional CF memory cards for easy storage or transfer to other devices such as personal computers.

Standard Specifications

Product name: Nitrogen Oxides Analyzer

Model Name: **GLN-314E**

Measurement Object: Nitrogen Oxides in ambient air Chemiluminescence method Measurement Method: Measurement Ranges: 0~0.1, 0~0.2, 0~0.5, 0~1, 0~2 ppm



Lower Detection Limit: 0.4 ppb

Zero Drift: Within 0.6 ppb/24 hours

Span Drift: Within ±1%FS/24 hours

Working Temperature

Range:

0 to 40 degC

Analogue Output: 0~1V (0~10V, 0~20mA, 4~20mA

available as options)

Digital Inputs/Outputs: RS-232, 8 status relay outputs, 5

digital inputs

Self Check and

Diagnostics:

Built-in

Re-start Function: Automatic start

Memory Backup: Equipped Pressure and Temp Equipped

Compensation:

Available with optional chassis Rack Mount:

slide rails


Operating Power: AC 100/115/220/230V, 50/60Hz


Dimensions (mm): 399(W)x528(D)x214(H) (main

body)

Weight: 20kg (approx.)

Outline & Mounting Dimensions





Due to continuous product improvement, specifications contained herein are subject to change without notice.



Always read the instruction manual before operation.

International Operations:

DKK-TOA Corporation 29-10, 1-Chome, Takadanobaba, Shinjuku-ku, Tokyo 169-8648 Japan Tel: +81-(0)3-3202-0225 Fax: +81-(0)3-3202-5685

Representative Office (Europe):

DKK-TOA European Representative St. Johns Innovation Centre, Cowley Rd., Cambridge CB4 0WS UK. Tel: +44 (0)1223-526471 Fax: +44 (0)1223-709239

www.dkktoa.net www.toadkk.co.jp

Local Representative: